

	A3	NE100-06-04	下部输送链轮				
	A4	NE100-06-03	平键				
	A4	NE100-06-02-1	挡销				
	A3	NE100-06-02	轴承座				
	A3	NE100-06-01	下部轴承盖				
		NE100-06-00	下部装配				
	A4	NE100-05-03	链套	A3	NE100-01A-01-3	维修架	
	A3	NE100-05-02	围板	A4	NE100-01A-01-2	三面槽钢法兰	
	A4	NE100-05-01	侧板	A3	NE100-01A-01-1	三面工作平台(B)	
		NE100-05-00A	料斗(加宽型)	A3	NE100-06-12	承重箱	
	A3	NE100-05-00	料斗	A4	NE100-06-11	连接板	
	A4	NE100jq-04-07	套筒	A4	NE100-06-10	杠杆	
	A4	NE100jq-04-06	内链板	A4	NE100-06-09	轴承座导轨	
	A4	NE100jq-04-05	滚子	A4	NE100-06-08-2	密封圈座	
	A4	NE100jq-04-04	龟板	A4	NE100-06-08-1	密封板	
	A4	同NE100-04-03	链销(加强型)	A4	NE100-06-08	密封板复合件	
	A4	NE100jq-04-02	外链板	A3	NE100-06-07	尾轴座	
	A4	NE100jq-04-01	销轴	A3	NE100-06-06-7	底座	
	A3	NE100jq-04-00	牵引链(加强型)	A4	NE100-06-06-6	杠杆座	
	A4	NE100-04-07	套筒	A4	NE100-06-06-5	活动门内法兰	
	A4	NE100-04-06	内链板	A4	NE100-06-06-4	后侧板	
	A4	NE100-04-05	滚子	A3	NE100-06-06-3	左(右)侧板	
	A4	NE100-04-04	龟板	A4	NE100-06-06-2	前侧板	
	A4	NE100-04-03	链销	A4	NE100-06-06-1-4	进料口后板	
	A4	NE100-04-02	外链板	A4	NE100-06-06-1-3	进料口侧板	
	A4	NE100-04-01	销轴	A4	NE100-06-06-1-2	进料口盖板	
	A3	NE100-04-00	牵引链(G型)	A4	NE100-06-06-1-1	进料口法兰	
	A4	NE100-03D-06	检修口法兰	A4	NE100-06-06-1	进料口	
	A4	NE100-03D-05	前(后)检修口盖		NE100-06-06	下部机壳	
	A4	NE100-03D-04	左(右)检修口盖	A4	NE100-06-05-3	加强筋	
	A4	NE100-03D-03	左(右)检修口法兰	A4	NE100-06-05-2	导轨固定板	
	A3	NE100-03D-02	左(右)带检修口侧板	A4	NE100-06-05-1	闷板	
	A4	NE100-03D-01	前(后)带检修口侧板	A3	NE100-06-05	活动门	
序号	幅面	代号	名称	序号	幅面	代号	名称

### 图样目录

NE100

板链斗式提升机

标记	处数	更改文件号	签字	日期
设计			标准化	
校对	李连通		批准	
审核	秦海波			
工艺	刘飞		日期	99.6.10

图样	标记	重量	比例
共	2	张	第 1 张



德欧环保  
DEOUHUANBAO  
环保社会 生态中国